GAMBIT 2.4

User's Guide

May 2007

Licensee acknowledges that use of Fluent, Inc.'s products can only provide an imprecise estimation of possible future performance and that additional testing and analysis, independent of the Licensor's products, must be conducted before any product can be finally developed or commercially introduced. As a result, Licensee agrees that it will not rely upon the results of any usage of Fluent, Inc.'s products in determining the final design, composition, or structure of any product.

© 1998–2007 by Fluent, Incorporated

All Rights Reserved. No part of this document may be reproduced or otherwise used in any form without express written permission from Fluent, Incorporated.

Airpak, FIDAP, FLUENT, GAMBIT, Icepak, MixSim, and POLYFLOW are registered trademarks of Fluent, Inc.

ImageMagick is © 1996 E.I. du Pont de Nemours and Co.

All other products or name brands are trademarks of their respective holders.

For GAMBIT Technical Support contact information, visit the Fluent, Inc. Web site at www.fluent.com.

Fluent, Incorporated
Centerra Resource Park
10 Cavendish Court
Lebanon, NH 03766

TABLE OF CONTENTS

1. INTRODUCTION 1-1
- **1.1 GAMBIT Documentation Suite 1-1**
- **1.2 Format and Font Conventions 1-2**
  - 1.2.1 Format Conventions 1-2
  - 1.2.2 Fonts 1-6
- **1.3 User's Guide—Outline 1-7**

2. STARTING GAMBIT 2-1
- **2.1 Startup Procedures 2-1**
  - 2.1.1 General Procedure 2-1
  - 2.1.2 PC Procedure 2-4
- **2.2 GAMBIT File Organization 2-7**
  - 2.2.1 Session Files 2-7
  - 2.2.2 Directory Structure 2-8
  - 2.2.3 File Management 2-9

3. THE GAMBIT GRAPHICAL USER INTERFACE (GUI) 3-1
- **3.1 GUI Components 3-2**
  - 3.1.1 Graphics Window 3-3
  - 3.1.2 Main Menu Bar 3-6
  - 3.1.3 Operation Toolpad 3-7
  - 3.1.4 Form Field 3-10
  - 3.1.5 Global Control Toolpad 3-10
  - 3.1.6 Description Window 3-11
  - 3.1.7 Transcript Window and Command Text Box 3-12
  - 3.1.8 GUI Sashes 3-14
  - 3.1.9 GUI Sash Anchor 3-14
- **3.2 GUI Control Elements 3-16**
  - 3.2.1 Command Buttons 3-18
  - 3.2.2 Option Buttons 3-19
  - 3.2.3 Radio Buttons 3-19
  - 3.2.4 Check Boxes 3-19
  - 3.2.5 Text Boxes 3-20
  - 3.2.6 List Boxes 3-20
  - 3.2.7 Text Windows 3-20
  - 3.2.8 Pick-List Forms 3-21
  - 3.2.9 Query-List Forms 3-25
  - 3.2.10 Slider Bars 3-27
- **3.3 Using the Mouse 3-28**
  - 3.3.1 Menus and Forms 3-28
  - 3.3.2 Graphics Window 3-29

3.4 Using the Global Control Toolpad 3-37
3.4.1 Quadrant Command Buttons 3-38
3.4.2 Control Command Buttons 3-39
Fit to Window 3-40
Select Pivot 3-41
Select Preset Configuration 3-42
Modify Lights 3-43
Annotate 3-45
Specify Label Type 3-52
Undo 3-54
Redo 3-55
Orient Model 3-56
Specify Display Attributes 3-66
Render Model 3-69
Specify Color Mode 3-70
Examine Mesh 3-72

4. GAMBIT MENU COMMANDS 4-1
4.1 File Commands 4-2
4.1.1 New 4-3
4.1.2 Open 4-5
4.1.3 Save 4-10
4.1.4 Save As 4-11
4.1.5 Print Graphics 4-12
4.1.6 Run Journal 4-16
4.1.7 Clean Journal 4-25
4.1.8 View File 4-31
4.1.9 Import 4-33
4.1.10 Export 4-84
4.1.11 Reconnect CAD 4-94
4.1.12 Exit 4-98
4.2 Edit Commands 4-99
4.2.1 Title 4-100
4.2.2 File 4-101
4.2.3 Parameters 4-103
4.2.4 Defaults 4-119
4.3 Solver Menu 4-124
4.4 Help Commands 4-125
4.4.1 Quick 4-125
4.4.2 Table of Contents 4-126
4.4.3 About 4-126

A. IF BLOCKS AND DO LOOPS A-1
A.1 Overview A-1

A.2 IF Blocks A-2
A.2.1 General Syntax A-2
A.2.2 Example A-3
A.2.3 Nested IF Blocks A-3
A.3 DO Loops A-4
A.3.1 General Syntax A-4
A.3.2 DO-Loop Operations A-4
A.3.3 Example A-5
A.3.4 BREAK and NEXT Commands A-6
A.3.5 Nested DO Loops A-6

B. CONSTANTS, FUNCTIONS, AND EXPRESSIONS B-1
B.1 Constants B-1
B.2 Functions B-2
B.2.1 Math Functions B-2
B.2.2 String Functions B-4
(=)—String Assignment B-4
(+)—String Concatenation B-5
CSTRCMP—Case-Insensitive String Compare B-6
CSTRNCMP—Case-Insensitive Substring Compare B-7
DIRNAME—Directory Path B-8
DIRPLUSFILE—Directory Path and File Name B-8
DIRPLUSSUBDIR—Directory and Subdirectory Path B-9
FILENAME—File Name/ Directory Path B-9
FILEPREFIX—Prefix of a File Name B-10
FILESUFFIX—Suffix of a File Name B-10
NTOS—Numeric-to-String Representation Conversion B-11
STON—String-to-Numeric Representation Conversion B-11
STRCMP—Case-Sensitive String Compare B-12
STRFMT—String Formatting B-13
STRLEN—Number of Characters in a String B-14
STRNCMP—Case-Sensitive Substring Compare B-14
STRRSTR—Offset of Last Substring Within a String B-15
STRSTR—Offset of First Substring Within a String B-15
STRTOLC—Convert a String to Lower Case B-15
STRTOUC—Convert a String to Upper Case B-16
SUBSTR—Substring Extraction B-16
B.2.3 System Functions B-17
FILEEXISTS—File Existence Flag B-17
GETCWD—Current Working Directory B-18
GETENV—Environment Variable B-18
PWD—Current Working Directory B-18
UNAME—Fluent Architecture Name B-19

WILDCARD—Filename List by Wildcard Reference B-19
B.2.4 Model Functions B-20
ARCLEN—Arc Length B-21
AREA—Surface Area B-22
BBOX—Bounding Box B-23
CADASSEMBLYPART—CAD Assembly Part Names B-23
CADCOMPONENT—Unassociated CAD Components B-24
CADPARAMETER—CAD Parameter Value B-24
DISTTOL—Model Distance Tolerance B-25
ELEMCOUNT—Numbers of Mesh Elements B-26
ENT2LOC—Entity Location B-27
ENTITYATTR—Entity Attribute Status B-28
ENTITYEXISTS—Entity Existence Flag B-29
ENTS_AT—Nearest Entities B-30
FACEFACEANGLE—Interior Angle Between Adjacent Faces B-31
FLUENTZONE—Fluent Solver Zone Assignments B-32
GETIDENT—Current GAMBIT Database Identifier B-32
GETNORMAL—Face Normal Vector B-33
GETSCR—Current Scratch Directory B-33
GETTANGENT—Edge Tangent Vector B-34
INTERIORANGLE—Interior Angle Between Adjacent Edges B-34
INTERIORFACE—Interior Face Flag B-35
INTERSECTING—Geometry Intersection Flag B-36
LASTID—Last Entity Identifier B-37
LISTENTITY—Entity List B-38
LOC2ENT—Entity with Nearest Centroid B-39
MESHCOPYLINKS—Mesh Copy Links B-40
MESHPARAMETERS—Mesh Parameters B-41
MINCLEARANCE—Minimum Clearance B-42
NDEFAULT—Numeric Default Value B-43
OPERERR—Error Flag B-43
PARAMLIST—Parameter List B-44
PARAMSIZE—Parameter Array Size B-44
QUALITY—Mesh Element Quality B-45
RETLABEL—Last n’th Entity Identifier B-47
SDEFAULT—String Default Value B-48
SLIVERWIDTH—Shortest Seamless Sliver Distance B-48
VIRTUALHOST—Host Entity Names B-49
VISIBLEGUEST—Guest Entity Names B-50
VOLUME—Volume (Mass) B-51
B.3 Expressions B-52
B.3.1 Arithmetic Expressions B-52
B.3.2 Logical Expressions B-53

C. GAMBIT NEUTRAL FILE FORMAT C-1
C.1 General Format C-1
C.1.1 Format Overview C-1
C.1.2 Format Description C-2
C.2 Element Type and Node-Numbering Conventions C-20
C.2.1 Edge, 2-Node C-20
C.2.2 Edge, 3-Node C-20
C.2.3 Quad, 4-Node C-21
C.2.4 Quad, 8-Node C-22
C.2.5 Quad, 9-Node C-23
C.2.6 Triangle, 3-Node C-24
C.2.7 Triangle, 6-Node C-25
C.2.8 Triangle, 7-Node C-26
C.2.9 Brick, 8-Node C-27
C.2.10 Brick, 20-Node C-27
C.2.11 Brick, 27-Node C-28
C.2.12 Wedge, 6-Node C-30
C.2.13 Wedge, 15-Node C-31
C.2.14 Wedge, 18-Node C-32
C.2.15 Tetrahedron, 4-Node C-33
C.2.16 Tetrahedron, 10-Node C-34
C.2.17 Pyramid, 5-Node C-35
C.2.18 Pyramid, 13-Node C-36
C.2.19 Pyramid, 14-Node C-37
C.2.20 Pyramid, 18-Node C-38
C.2.21 Pyramid, 19-Node C-39
C.3 Example GAMBIT Neutral File C-40

D. GAMBIT TURBO FILE FORMAT D-1
D.1 General Structure D-2
D.1.1 Header Information D-2
D.1.2 Hub, Casing, and Tip-Clearance Data D-6
D.1.3 Blade Data D-11
D.2 Example GAMBIT Turbo File D-20